M51

Air Valves: Air-Release, Air/Vacuum & Combination





M51

Air-Valves:

Air-Release, Air/Vacuum and Combination

Second Edition



Manual of Water Supply Practices—M51, Second Edition

Air Valves: Air-Release, Air/Vacuum and Combination

Copyright © 2001, 2016 American Water Works Association

All rights reserved. No part of this publication may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopy, recording, or any information or retrieval system, except in the form of brief excerpts or quotations for review purposes, without the written permission of the publisher.

Disclaimer

The authors, contributors, editors, and publisher do not assume responsibility for the validity of the content or any consequences of its use. In no event will AWWA be liable for direct, indirect, special, incidental, or consequential damages arising out of the use of information presented in this book. In particular, AWWA will not be responsible for any costs, including, but not limited to, those incurred as a result of lost revenue. In no event shall AWWA's liability exceed the amount paid for the purchase of this book.

If you find errors in this manual, please email books@awwa.org. Possible errata will be posted at www. awwa.org/resources-tools/resource.development.groups/manuals-program.aspx.

Managing Editor-Book Products: Melissa Valentine Production: Janice Benight Cover design: Melanie Yamamoto

Library of Congress Cataloging-in-Publication Data

Names: Ballun, John V., author. | American Water Works Association, issuing body.

Title: Air-release, air/vacuum, and combination air valves / by John V. Ballun.

Other titles: AWWA manual; M51.

Description: Second edition. | Denver, CO: American Water Works Association,

[2016] | Series: Manual of water supply practices; M51 | Includes

bibliographical references and index.

Identifiers: LCCN 2016019688 | ISBN 9781625761767 Subjects: LCSH: Water-pipes--Valves | Air valves. Classification: LCC TD491 .B34 2016 | DDC 628.1/5--dc23 LC record available at https://lccn.loc.gov/2016019688

Printed in the United States of America

ISBN 978-1-62576-176-7 eISBN-13 978-1-61300-387-9



This AWWA content is the product of thousands of hours of work by your fellow water professionals. Revenue from the sales of this AWWA material supports ongoing product development. Unauthorized distribution either electronic or photocopied, is illegal and hinders AWWA's mission to support the water community.



American Water Works Association 6666 West Quincy Avenue Denver, CO 80235-3098 awwa.org

Contents

Figures, v Tables, vii Preface, ix Acknowled	lgments, xi
Chapter 1	Introduction
Chapter 2	Types of Air Valves
Chapter 3	Locating Air Valves Along a Liquid Piping System at Filling, Steady State Flow, and Drainage
Chapter 4	Design of Valve Orifice Size
Chapter 5	Water Hammer Effects
Chapter 6	Installation, Operation, Maintenance, and Safety

Bibliography, 55 Index, 57 AWWA Manuals, 61

Figures

Figure 1-1	Air and wastewater gas pocket in a pipeline, 3
Figure 1-2	An air valve installed on the outlet of a pump and upstream of the check valve, 4
Figure 2-1	Air-release valves, 8
Figure 2-2	Air/vacuum valves, 9
Figure 2-3	Single-body combination air valves, 10
Figure 2-4	Dual-body combination air valves, 11
Figure 2-5	Dual-body combination air valve (3 in. [80 mm] and smaller) for water service, bottom-mounted, 11
Figure 2-6	Backwash connections, 12
Figure 2-7	Air/vacuum and combination air valves with slow-closing device, 13
Figure 2-8	Two examples of throttling devices, 14
Figure 2-9	Installation of a throttling device, 14
Figure 2-10	Air valve with vacuum check device on the outlet, 15
Figure 2-11	A single-body combination air valve mounted on a pipe header, 15
Figure 3-1	Sample liquid piping system profile illustrating typical air valve locations, 18
Figure 3-2	Siphon with an air valve, 20
Figure 3-3	Siphon make-and-break air valve with flow paddle, 21
Figure 3-4	Penstock, 21
Figure 4-1	Inflow of air for gravity flow, SCFM, 29
Figure 4-2	Example of air valve locations for gravity flow along a pipe, 32
Figure 4-3	Vacuum breaker with air-release valve, 35
Figure 5-1	Air/vacuum valve or combination air valve at a well pump, 43
Figure 6-1	Installation of an air valve with shutoff valve, 46
Figure 6-2	Automatic freeze protection valve, 48
Figure 6-3	Belowground air valve vault installation of a combination air valve (not subject to flooding), 49
Figure 6-4	Custom vault installation of a combination air valve for servicing aboveground, 50
Figure 6-5	Vault installation of a combination air valve with plumbed exhaust, 51
_	Vault installation with freeze and flood protection, 52

This page intentionally blank.

Tables

- 1-1 Velocities required to scour air and wastewater gases from pipelines, 2
- 4-1 Air and wastewater gases capacity table (SCFM [L/sec]) of air-release valve orifices ($C_d = 0.6$), 25
- 4-2 Air and wastewater gas discharge table (SCFM [L/sec]) of large orifices (C_d = 0.6, T = 60°F ([15.5°C]), and sea level), 27
- 4-3 Air inflow table of large orifices (SCFM [L/sec]) ($C_d = 0.6$), 30
- 4-4 Nominal areas of single and multiple air valves, 37

This page intentionally blank.