

# Aquifer Storage and Recovery



**American Water Works  
Association**

This is a preview. [Click here to purchase the full publication.](#)

## Aquifer Storage and Recovery

Copyright © 2015 American Water Works Association

All rights reserved. No part of this publication may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopy, recording, or any information or retrieval system, except in the form of brief excerpts or quotations for review purposes, without the written permission of the publisher.

### Disclaimer

The authors, contributors, editors, and publisher do not assume responsibility for the validity of the document or any consequences of its use. In no event will AWWA be liable for direct, indirect, special, incidental, or consequential damages arising out of the use of information presented in this book. In particular, AWWA will not be responsible for any costs, including, but not limited to, those incurred as a result of lost revenue. In no event shall AWWA's liability exceed the amount paid for the purchase of this book.

Sr. Manager, Editorial, Development and Production: Gay Porter DeNileon  
Senior Manuals Specialist: Molly Beach  
Production: TIPS Technical Publishing, Inc.

If you find errors in this manual, please email [books@awwa.org](mailto:books@awwa.org). Possible errata will be posted at [www.awwa.org/resources-tools/resource.development.groups/manuals-program.aspx](http://www.awwa.org/resources-tools/resource.development.groups/manuals-program.aspx).

---

### Library of Congress Cataloging-in-Publication Data

Bloetscher, Frederick, author.

Aquifer storage and recovery / Frederick Bloetscher. — First edition.

pages cm. — (Manual of water supply practices ; M63)

Includes bibliographical references and index.

ISBN 978-1-62576-104-0


1. Aquifer storage recovery—United States. I. Title. II. Series: AWWA manual ; M63.

TD404.5.B55 2015

628.1'3—dc23

2015011138

---



ISBN-13 978-1-62576-104-0

eISBN-13 978-1-61300-340-4

Printed in the United States of America  
American Water Works Association  
6666 West Quincy Avenue  
Denver, CO 80235-3098  
[awwa.org](http://awwa.org)



Printed on  
recycled paper

This is a preview. [Click here to purchase the full publication.](#)

# Figures



- 1-1 (a) Aquifer recharge; (b) Aquifer recharge via flooding, 2
- 1-2 (a) Biscayne Aquifer reclamation after start of injection; (b) Biscayne Aquifer reclamation water movement after injection; (c) Biscayne Aquifer reclamation water movement toward saltwater after injection; (d) Biscayne Aquifer reclamation water movement pushing isochlor line toward the ocean, 4
- 1-3 Aquifer storage and recovery conceptual diagram for brackish water aquifers where freshwater bubble creates mixing transition zone that increases with time, 5
  
- 2-1 Different classes of wells, 9
- 2-2 States with ASR-specific statutes or rules, 15
- 2-3 United States ASR projects from 1985–present, 16
  
- 3-1 Number of ASR sites by state, 20
- 3-2 Cumulative ASR sites by decade, 20
- 3-3 Sources of water used for ASR programs, 21
- 3-4 Uses of water recovered from ASR wells, 21
- 3-5 Injection horizon formation type, 22
- 3-6 Confining unit formation type, 22
  
- 5-1 Parts of the ASR well; assume cementing between all casings for most ASR wells, 51
- 5-2 Casing material used in ASR wells, 51
- 5-3 Casing diameter of ASR wells, 52
- 5-4 TDS of the injection horizon for Florida wells that inject into brackish water, 55
- 5-5 Basic configuration for injection piping and withdrawal piping for submersible pump, 56
- 5-6 Basic configuration for vertical turbine pump (in test mode), 56
- 5-7 Basic configuration for injection piping and withdrawal piping for vertical turbine pump, 57
- 5-8 Components of a wellhead, 57
- 5-9 Number of cycles of injection/recovery per site, 60
  
- 6-1 Pump design curve and data, 66
- 6-2 The components of pumping-induced drawdown at a well related to aquifer hydraulics and well design, 68
  
- 7-1 Schematic of Peace River ASR system, 74
- 7-2 Cross section of the Peace River ASR system, 75
- 7-3 Injection and withdrawal cycles of Willow Water District’s Well 6, 1991–1995, 77
- 7-4 ASR injection and recovery cycles for the Lake Okeechobee Project, 80

# Tables



- 2-1 USEPA classification system for injection wells (Adapted from 40 CFR 144.6), 9
- 6-1 Typical well and pump operational record form, 67

# Acronyms

AFA	acre-ft annually
AGWT/HC/FGS	American Groundwater Trust/Hydrogeology Consortium/Florida Geological Survey
ASCE-EWRI	American Society of Civil Engineers – Environmental & Water Resources Institute
ASR	aquifer storage and recovery
CAP	Central Arizona Project
CBOD <sub>5</sub>	5-day carbonaceous biological oxygen demand
CERP	Comprehensive Everglades Restoration Plan
CFR	Code of Federal Regulations
DBPs	disinfection by-products
DWR	Department of Water Resources
FAC	Florida Administrative Code
fpd	feet per day
GEFA	Georgia Environmental Finance Authority
gpd/ft	gallons per day/foot
gpd/ft <sup>2</sup>	gallons per day/square foot
gpm	gallons per minute
gpm/ft	gallons per minute/foot
GSWSA	Grand Strand Water and Sewer Authority
H <sup>+</sup>	hydrogen ion
HAAs	haloacetic acids
ID	internal diameter
K	hydraulic conductivity
LVV	Las Vegas Valley
MCL	maximum contaminant levels
mgd	million gallons per day
mi <sup>2</sup>	square miles
MLGW	Memphis Light Gas and Water
Mn	manganese
NOM	natural organic matter
NPSH	net positive suction head
NTU	nephelometric turbidity units
OD	outside diameter
OH <sup>-</sup>	hydroxide ion
ORP	oxidation–reduction potential
PAD	prior appropriation doctrine
PRRWSF	Peace River Regional Water Supply Facility

PVC	polyvinyl chloride
POS	plan of study
SCADA	supervisory control and data acquisition
SDWA	Safe Drinking Water Act
SFWMD	South Florida Water Management District
SWPP	source water protection program
TDH	total dynamic head
TDS	total dissolved solids
THMs	trihalomethanes
TOC	total organic carbon
TSS	total suspended solids
TSWB	Texas State Water Board
TTHM	total trihalomethanes
UIC	underground injection control
USDW	underground sources of drinking water
USEPA	United States Environmental Protection Agency
USGS	United States Geological Survey
VFD	variable-frequency drive
WCASF	Water Conservation Areas of South Florida
WEFTEC	Water Environment Federation Technical Exhibition and Conference
WWTP	wastewater treatment plant
ZOC	zone of contribution

# Contents

Figures, v	
Tables, vii	
Foreword, ix	
Acknowledgments, xi	
Acronyms, xv	
<b>Chapter 1</b>	<b>Groundwater Recharge and Storage Programs..... 1</b>
	Artificial Aquifer Creation and Aquifer Recharge, 1
	Aquifer Reclamation, 3
	Aquifer Storage and Recovery, 3
	References, 6
<b>Chapter 2</b>	<b>Regulatory Requirements..... 7</b>
	Federal Regulations – UIC, 8
	Aquifer Exemptions, 10
	Zones of Discharge, 12
	Water Rights and Allocations by Rule, 12
	Wellhead and Source Water Protection, 13
	State Regulations for Injection Programs, 14
	Use of Waters of Impaired Quality, 16
	References, 17
<b>Chapter 3</b>	<b>Summary of ASR Programs in the United States..... 19</b>
	ASR Sites in the United States, 19
	Individual State ASR Systems, 23
	References, 32
<b>Chapter 4</b>	<b>Challenges for ASR Programs in the United States ..... 33</b>
	Clogging, 33
	Water Quality, 37
	Low Recovery and Expectations , 40
	References, 41
<b>Chapter 5</b>	<b>Planning and Construction of ASR Systems..... 45</b>
	Plan of Study, 46
	Feasibility Study, 47
	Pilot-Testing Program, 49
	Well Design, 50
	Water Quality, 53
	Well Construction, 54
	Wellhead, 55
	Well Acceptance and Pumping Test, 58
	Storage Zone Development, 58
	Design and Construction Records, 60
	References, 61

<b>Chapter 6</b>	<b>Operation and Performance Monitoring of ASR Wells</b> .....	<b>63</b>
	Data Management,	63
	Other Operation and Performance Considerations,	69
	Well Abandonment,	70
	References,	71
<b>Chapter 7</b>	<b>Example ASR Programs in US</b> .....	<b>73</b>
	Peace River ASR Project,	73
	Denver Basin ASR Project,	76
	Comprehensive Everglades Restoration Plan Pilot,	78
	Collier County, Florida, Project,	80
	Memphis, Tennessee, Project,	82
	Horry County, South Carolina, Projects,	83
	Roseville, California,	84
	Conclusions,	85
	References,	86
<b>Chapter 8</b>	<b>ASR Versus Other Groundwater Recharge and Storage Programs</b> .....	<b>87</b>
<b>Appendix A</b>	<b>US ASR Systems</b> .....	<b>89</b>
<b>Appendix B</b>	<b>Canadian ASR Experience</b> .....	<b>103</b>
	<b>Glossary,</b>	<b>105</b>
	<b>Bibliography,</b>	<b>111</b>
	<b>Index,</b>	<b>125</b>
	<b>AWWA Manuals,</b>	<b>129</b>



Chapter **1**

# Groundwater Recharge and Storage Programs

In some areas of the world, vast amounts of treated or treatable water are being pumped below ground and stored beneath the earth's surface to preserve current water resources, prepare for future droughts, protect water resources, recharge wellfields, and store water for use at a later time to sustain development. Belowground storage holds an advantage over surface reservoirs because no evaporation losses occur. Water resources are also conserved because water not needed presently is stored, instead of being discharged into rivers, oceans, or other surface waterways.

Groundwater recharge and storage programs are divided into four categories: artificial aquifer creation, aquifer recharge, aquifer reclamation, and aquifer storage and recovery (ASR). All methods can be part of a water supplier's program of ensuring that sustainable water supplies are available for agricultural, environmental, and urban uses. Most methods are employed in arid or coastal areas or in areas with seasonal wet and dry periods, and also serve as a supplemental source in the event of emergency outages, low fire flows, and water quality issues (via blending). These strategies are employed in Australia, Europe, the Middle East, and the United States. At present, all of these strategies have proven cost effective and capable of successfully augmenting existing water sources for long-term water supply under certain conditions.

## ARTIFICIAL AQUIFER CREATION AND AQUIFER RECHARGE

Artificial aquifer creation technologies involve the introduction of large quantities of water into an aquifer or aquifer zone for retrieval down-gradient of the point of injection. Prior to injection, the aquifer is generally either devoid of water or contains low-quality water. In areas with limited demand, but where porosities or strata may allow for water storage, artificial aquifer recharge is applicable because it is specifically meant to encourage

recharge and therefore requires high-quality water for injection. Because groundwater movement is generally slow, the recharge program may be able to supply either small quantities of water or supplement existing water during times of high demand that could cause aquifer stress.

Where an aquifer has been depleted by overpumping (mining of the aquifer), aquifer recharge, also termed artificial recharge, is a viable concept. This concept uses water of a given quality introduced at a point that enables existing water supplies to flow into a wellfield production zone. The aquifer head is raised enough to create a driving force that pushes water into the aquifer formations, where the water can be eventually pumped via a wellfield, which could be many miles away (Figures 1-1a and 1-1b).

Sometimes a surface area is simply flooded to create an artificial aquifer head at the point of recharge. The higher surface water head increases the percolation rate into the aquifer. One drawback with flooding areas is that surface water has a higher evapotranspiration rate than do other forms of aquifer recharge. However, downstream well fields benefit from the resulting higher water levels with increased total water supplies.

The Water Conservation Areas of South Florida (WCASF) are examples of aquifer recharge via flooding. The WCASF store water at higher-than-normal levels to force recharge of the Biscayne Aquifer system. The aquifer's natural gradient toward the coast allows the recharge to serve most of the South Florida utilities in some manner. Other such programs exist in Texas, Arizona, Utah, California, and other states, but artificial aquifer creation and aquifer recharge programs are outside the scope of this manual.




Figure 1-1 (a) Aquifer recharge; (b) Aquifer recharge via flooding

Source: AWWA 2014

## AQUIFER RECLAMATION

Aquifer reclamation involves injecting large quantities of higher-quality waters into a compromised aquifer. One application of this technology is injection of freshwater into aquifer zones that have been compromised by brackish water (water containing 1,000 to 10,000 ppm of total dissolved solids) intruding into the formation (USEPA 2002). The freshwater serves to stabilize the water quality at a given chloride (isochlor) concentration or forces the brackish water to retreat toward the source—typically the ocean, but also lower formations where *upconing* is a problem. Upconing is the process by which saline water underlying freshwater in an aquifer rises upward into the freshwater zone as a result of pumping water from the freshwater zone. Aquifer reclamation has not been used in North America to a great extent except in California, but the technical concept has wide applicability in coastal areas with transmissive formations where saltwater intrusion has occurred or has the potential to occur, as a result of lowered surface water levels or where *connate water*—water trapped within the pores of rock formations—may be present. The method can also be applied to well fields where upconing of brackish or water containing high total dissolved solids from lower aquifer regions is a potential problem, thereby allowing withdrawals of larger quantities without inducing upconing.

Artificially-induced saline encroachment (intrusion) can be initiated when the aquifer head in a given area is sufficiently reduced by aquifer withdrawals, development over surface recharge areas reduces permeability (as a result of buildings and paving), or drainage canals discharge surface water that might otherwise percolate into the aquifer. Saltwater can continue to migrate inland over time, contaminating the aquifer. Initially the water movement is slow, but it accelerates as the saltwater draws closer to withdrawal (discharge) points. A hydrogeologically sound injection program, properly designed and constructed, can mitigate the landward migration of the saltwater. Under certain scenarios, the movement of the saltwater can be reversed (Figures 1-2a, 1-2b, 1-2c, and 1-2d). Chapter 11 of M21, *Groundwater* (AWWA 2014), and Bloetscher et al. (2005) discuss this concept in more detail.

## AQUIFER STORAGE AND RECOVERY

That leaves us with the topic of this manual: aquifer storage and recovery, or ASR. ASR involves the management of water supplies for both potable (drinking water) and non-potable water supply systems. While the purpose of both aquifer reclamation and aquifer recharge is to sustain long-term demands in an existing or potential source, ASR is intended to store water until such time as it is needed to meet peak needs, long-term growth demands, or emergency conditions, or because of poor water quality.

More than 200 sites in 27 different states in the United States have either implemented or investigated ASR. Most existing systems involve storage of potable water, but a number of wells use untreated raw surface water or groundwater in an ASR system for later withdrawal and treatment. The goal of these projects is to store current water supplies for later use, both long and short term. As water supplies have become more limited in more areas of the country, additional interest has developed in the practice of incorporating ASR into potable water, irrigation, and reclaimed systems.

Employing ASR technology can increase the efficiency of water system operation. During a wet or low-demand time of the year, some or all of the unused water treatment plant capacity can be used to treat water and inject the treated water into an aquifer for future recovery and use. The potable water to be stored is injected into the aquifer (Figure 1-3) where it displaces the native groundwater in the aquifer. The storage zone should have good overlying confinement, underlying semi-confinement, and a transmissivity commensurate with the storage and recovery capacity goals of the program. In the ASR concept, native water is theoretically displaced and replaced in the injection zone,